

**- COVER PAGE -
ANALYSIS DATA PACKAGE**

Client: Nobis Group

SDG No.: P5306 Method Type: EPA SW846 8260 SOW No.: _____

Contract: NOBI03 Lab Code: CHEM Case No.: P5306 SAS No.: P5306

<u>Lab Sample ID</u>	<u>Client Sample ID</u>	<u>QC Description</u>
<u>P5306-01</u>	<u>OU4-VSL-07-121224</u>	
<u>P5306-03</u>	<u>OU4-VSL-08-121224</u>	
<u>P5306-05</u>	<u>OU4-VSL-09-121224</u>	
<u>P5306-07</u>	<u>OU4-VSL-10-121224</u>	
<u>P5306-09</u>	<u>OU4-VSL-11-121224</u>	
<u>P5306-09RE</u>	<u>OU4-VSL-11-121224RE</u>	
<u>P5306-11</u>	<u>OU4-VSL-12-121224</u>	
<u>P5306-13</u>	<u>OU4-VSL-13-121224</u>	
<u>P5306-13RE</u>	<u>OU4-VSL-13-121224RE</u>	
<u>P5306-15</u>	<u>OU4-VSL-14-121224</u>	
<u>VY1219SBL01</u>	<u>VY1219SBL01</u>	<u>Method Blank</u>
<u>VY1219SBS01</u>	<u>VY1219SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY1220SBL01</u>	<u>VY1220SBL01</u>	<u>Method Blank</u>
<u>VY1220SBS01</u>	<u>VY1220SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY1220SBSD01</u>	<u>VY1220SBSD01</u>	<u>Laboratory Control Sample Duplicate</u>
<u>VY1223SBL01</u>	<u>VY1223SBL01</u>	<u>Method Blank</u>
<u>VY1223SBS01</u>	<u>VY1223SBS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: shreena

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** shreena

Date: _____ **Title:** Analyst