

SOIL TPH GC LABORATORY CONTROL SPIKE/LABORATORY CONTROL SPIKE DUPLICATE RECOVERY

Lab Name: Chemtech **Client:** PARSONS Engineering of New York, Inc.
Lab Code: CHEM **Cas No:** P5361 **SAS No :** P5361 **SDG No:** P5361
Matrix Spike - EPA Sample No : PB165807BS **Datafile:** FG015025.D

COMPOUND	SPIKE ADDED ug/kg	CONCENTRATION ug/kg	LCS/LCSD CONCENTRATION ug/kg	% REC	QC LIMITS
Petroleum Hydrocarbons	11326	0	8193	72	68-131