

- COVER PAGE -
ANALYSIS DATA PACKAGE

Client: Tetra Tech NUS, Inc.

SDG No.: Q1380 Method Type: EPA SW846 8260 SOW No.: _____

Contract: TETR06 Lab Code: CHEM Case No.: Q1380 SAS No.: Q1380

Lab Sample ID	Client Sample ID	QC Description
<u>Q1380-01</u>	<u>BP-VPB-192-EB-20250212</u>	_____
<u>Q1380-02</u>	<u>BP-VPB-192-TB-20250210</u>	_____
<u>Q1380-06</u>	<u>BP-VPB-192-GW-725-727</u>	_____
<u>Q1380-07MS</u>	<u>BP-VPB-192-GW-725-727MS</u>	<u>Matrix Spike</u>
<u>Q1380-08MSD</u>	<u>BP-VPB-192-GW-725-727MSD</u>	<u>Matrix Spike Duplicate</u>
<u>Q1380-09</u>	<u>BP-VPB-192-GW-780-782</u>	_____
<u>Q1380-12</u>	<u>VPB192-HYD-20250214</u>	_____
<u>VN0219WBL01</u>	<u>VN0219WBL01</u>	<u>Method Blank</u>
<u>VN0219WBS01</u>	<u>VN0219WBS01</u>	<u>Laboratory Control Sample</u>
<u>VN0219WBSD01</u>	<u>VN0219WBSD01</u>	<u>Laboratory Control Sample Duplicate</u>
<u>VY0219SBL01</u>	<u>VY0219SBL01</u>	<u>Method Blank</u>
<u>VY0219SBS01</u>	<u>VY0219SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0226SBL01</u>	<u>VY0226SBL01</u>	<u>Method Blank</u>
<u>VY0226SBS01</u>	<u>VY0226SBS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: Shreena

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** Shreena

Date: _____ **Title:** Analyst