



Contract:	<u>NOBI03</u>						
Lab Code:	<u>CHEM</u>	Case No.:	<u>Q1382</u>	SAS No.:	<u>Q1382</u>	SDG NO.:	<u>Q1382</u>
Instrument ID:	<u>ECD_S</u>	Calibration Date(s):		<u>02/19/2025</u>	<u>02/19/2025</u>		
		Calibration Times:		<u>10:21</u>	<u>11:57</u>		

LAB FILE ID:	RT 200 =	<u>PS029191.D</u>	RT 500 =	<u>PS029192.D</u>
RT 750 =	<u>PS029193.D</u>	RT 1000 =	<u>PS029194.D</u>	RT 1500 =
			<u>PS029195.D</u>	

[illegible]



Contract:	<u>NOBI03</u>						
Lab Code:	<u>CHEM</u>	Case No.:	<u>Q1382</u>	SAS No.:	<u>Q1382</u>	SDG NO.:	<u>Q1382</u>
Instrument ID:	<u>ECD_S</u>	Calibration Date(s):		<u>02/19/2025</u>	<u>02/19/2025</u>		
		Calibration Times:		<u>10:21</u>	<u>11:57</u>		

LAB FILE ID:	RT 200 =	<u>PS029191.D</u>	RT 500 =	<u>PS029192.D</u>
RT 750 =	PS029193.D	RT 1000 =	PS029194.D	RT 1500 = PS029195.D

[illegible]