

- COVER PAGE -
ANALYSIS DATA PACKAGE

Client: Nobis Group

SDG No.: Q1382 Method Type: EPA SW846 8260 SOW No.: _____

Contract: NOBI03 Lab Code: CHEM Case No.: Q1382 SAS No.: Q1382

<u>Lab Sample ID</u>	<u>Client Sample ID</u>	<u>QC Description</u>
<u>Q1382-01</u>	<u>OU4-PCS-TC-01-021725</u>	
<u>Q1382-03</u>	<u>OU4-PCS-TC-02-021725</u>	
<u>Q1382-05</u>	<u>OU4-PCS-TC-03-021725</u>	
<u>Q1382-07</u>	<u>OU4-PCS-TC-04-021725</u>	
<u>Q1382-09</u>	<u>OU4-PCS-TC-05-021725</u>	
<u>Q1382-11</u>	<u>OU4-PCS-TC-06-021725</u>	
<u>Q1382-13</u>	<u>OU4-PCS-TC-07-021725</u>	
<u>Q1382-15</u>	<u>OU4-PCS-TC-08-021725</u>	
<u>Q1382-17</u>	<u>OU4-PCS-TC-09-021725</u>	
<u>Q1382-19</u>	<u>OU4-PCS-TC-10-021725</u>	
<u>VY0219SBL01</u>	<u>VY0219SBL01</u>	<u>Method Blank</u>
<u>VY0219SBS01</u>	<u>VY0219SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0221SBL01</u>	<u>VY0221SBL01</u>	<u>Method Blank</u>
<u>VY0221SBS01</u>	<u>VY0221SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0226SBL01</u>	<u>VY0226SBL01</u>	<u>Method Blank</u>
<u>VY0226SBS01</u>	<u>VY0226SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0226SBSD01</u>	<u>VY0226SBSD01</u>	<u>Laboratory Control Sample Duplicate</u>

Comments: _____

Signature: _____ Name: maresh

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** maresh

Date: _____ **Title:** Analyst