

**- COVER PAGE -
ANALYSIS DATA PACKAGE**

Client: Nobis Group

SDG No.: Q1383 Method Type: EPA SW846 8260 SOW No.: _____

Contract: NOBI03 Lab Code: CHEM Case No.: Q1383 SAS No.: Q1383

<u>Lab Sample ID</u>	<u>Client Sample ID</u>	<u>QC Description</u>
<u>Q1383-01</u>	<u>OU4-PCS-TC-11-021725</u>	
<u>Q1383-03</u>	<u>OU4-PCS-TC-12-021725</u>	
<u>Q1383-05</u>	<u>OU4-PCS-TC-13-021725</u>	
<u>Q1383-07</u>	<u>OU4-PCS-TC-14-021725</u>	
<u>Q1383-09</u>	<u>OU4-PCS-TC-15-021725</u>	
<u>Q1383-11</u>	<u>OU4-PCS-TC-16-021725</u>	
<u>Q1383-13</u>	<u>OU4-PCS-TC-17-021725</u>	
<u>Q1383-15</u>	<u>OU4-PCS-TC-18-021725</u>	
<u>Q1383-17</u>	<u>OU4-PCS-TC-19-021725</u>	
<u>Q1383-19</u>	<u>OU4-PCS-TC-20-021725</u>	
<u>Q1383-21</u>	<u>OU4-CF-15-021725</u>	
<u>VY0221SBL01</u>	<u>VY0221SBL01</u>	<u>Method Blank</u>
<u>VY0221SBS01</u>	<u>VY0221SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0226SBL01</u>	<u>VY0226SBL01</u>	<u>Method Blank</u>
<u>VY0226SBS01</u>	<u>VY0226SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0226SBSD01</u>	<u>VY0226SBSD01</u>	<u>Laboratory Control Sample Duplicate</u>

Comments: _____

Signature: _____ Name: nishadh

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** nishadh

Date: _____ **Title:** Analyst