

- COVER PAGE -
ANALYSIS DATA PACKAGE

Client: Portal Partners Tri-Venture

SDG No.: Q1488 Method Type: EPA SW846 8260 SOW No.: _____

Contract: PORT06 Lab Code: CHEM Case No.: Q1488 SAS No.: Q1488

<u>Lab Sample ID</u>	<u>Client Sample ID</u>	<u>QC Description</u>
<u>Q1488-01</u>	<u>ENV-101-SB01</u>	
<u>Q1488-03</u>	<u>ENV-101-SB02</u>	
<u>Q1488-05</u>	<u>ENV-102-SB01</u>	
<u>Q1488-07</u>	<u>ENV-102-SB02</u>	
<u>Q1488-09</u>	<u>ENV-104-SB01</u>	
<u>Q1488-11</u>	<u>ENV-104-SB02</u>	
<u>Q1488-13</u>	<u>ENV-102-GW01</u>	
<u>Q1488-14</u>	<u>ENV-104-GW01</u>	
<u>Q1488-14DL</u>	<u>ENV-104-GW01DL</u>	
<u>Q1488-15</u>	<u>TB03042025</u>	
<u>VX0305WBL01</u>	<u>VX0305WBL01</u>	<u>Method Blank</u>
<u>VX0305WBS01</u>	<u>VX0305WBS01</u>	<u>Laboratory Control Sample</u>
<u>VX0305WBSD01</u>	<u>VX0305WBSD01</u>	<u>Laboratory Control Sample Duplicate</u>
<u>VX0306WBL01</u>	<u>VX0306WBL01</u>	<u>Method Blank</u>
<u>VX0306WBS01</u>	<u>VX0306WBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0306SBL01</u>	<u>VY0306SBL01</u>	<u>Method Blank</u>
<u>VY0306SBS01</u>	<u>VY0306SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0306SBSD01</u>	<u>VY0306SBSD01</u>	<u>Laboratory Control Sample Duplicate</u>
<u>VY0307SBL01</u>	<u>VY0307SBL01</u>	<u>Method Blank</u>
<u>VY0307SBS01</u>	<u>VY0307SBS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: nishadh

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** nishadh

Date: _____ **Title:** Analyst