

- COVER PAGE -
ANALYSIS DATA PACKAGE

Client: Nobis Group

SDG No.: Q1883 Method Type: EPA SW846 8260 SOW No.: _____

Contract: NOBI03 Lab Code: CHEM Case No.: Q1883 SAS No.: Q1883

<u>Lab Sample ID</u>	<u>Client Sample ID</u>	<u>QC Description</u>
<u>Q1883-01</u>	<u>OU4-PCS-TC-27-042325</u>	
<u>Q1883-03</u>	<u>OU4-PCS-TC-28-042325</u>	
<u>Q1883-05</u>	<u>OU4-PCS-TC-29-042325</u>	
<u>Q1883-07</u>	<u>OU4-PCS-TC-30-042325</u>	
<u>Q1883-09</u>	<u>OU4-PCS-TC-31-042325</u>	
<u>Q1883-11</u>	<u>OU4-PCS-TC-32-042325</u>	
<u>Q1883-13</u>	<u>OU4-VSL-18-042325</u>	
<u>Q1883-15</u>	<u>OU4-VSL-19-042325</u>	
<u>Q1883-17</u>	<u>SO-TB-01-042325</u>	
<u>VY0429SBL01</u>	<u>VY0429SBL01</u>	<u>Method Blank</u>
<u>VY0429SBS01</u>	<u>VY0429SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0429SBSD01</u>	<u>VY0429SBSD01</u>	<u>Laboratory Control Sample Duplicate</u>
<u>VY0430SBL01</u>	<u>VY0430SBL01</u>	<u>Method Blank</u>
<u>VY0430SBS01</u>	<u>VY0430SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0501SBL01</u>	<u>VY0501SBL01</u>	<u>Method Blank</u>
<u>VY0501SBS01</u>	<u>VY0501SBS01</u>	<u>Laboratory Control Sample</u>
<u>VY0505SBL01</u>	<u>VY0505SBL01</u>	<u>Method Blank</u>
<u>VY0505SBS01</u>	<u>VY0505SBS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: Pratha

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** Pratha

Date: _____ **Title:** Analyst