



Contract:	<u>NOBI03</u>						
Lab Code:	<u>CHEM</u>	Case No.:	<u>Q2259</u>	SAS No.:	<u>Q2259</u>	SDG NO.:	<u>Q2259</u>
Instrument ID:	<u>ECD_S</u>	Calibration Date(s):		<u>06/16/2025</u>	<u>06/16/2025</u>		
		Calibration Times:		<u>09:56</u>	<u>11:33</u>		

LAB FILE ID:	RT 200 =	<u>PS030681.D</u>	RT 500 =	<u>PS030682.D</u>
RT 750 =	<u>PS030683.D</u>	RT 1000 =	<u>PS030684.D</u>	RT 1500 =
			<u>PS030685.D</u>	

[illegible]



Contract:	<u>NOBI03</u>						
Lab Code:	<u>CHEM</u>	Case No.:	<u>Q2259</u>	SAS No.:	<u>Q2259</u>	SDG NO.:	<u>Q2259</u>
Instrument ID:	<u>ECD_S</u>	Calibration Date(s):		<u>06/16/2025</u>	<u>06/16/2025</u>		
		Calibration Times:		<u>09:56</u>	<u>11:33</u>		

LAB FILE ID:	RT 200 =	<u>PS030681.D</u>	RT 500 =	<u>PS030682.D</u>
RT 750 =	<u>PS030683.D</u>	RT 1000 =	<u>PS030684.D</u>	RT 1500 =
			<u>PS030685.D</u>	

[illegible]