

**- COVER PAGE -
ANALYSIS DATA PACKAGE**

Client: GFE LLC

SDG No.: Q3320 Method Type: EPA SW846 TO-15 SOW No.: _____

Contract: GFEL01 Lab Code: CHEM Case No.: Q3320 SAS No.: Q3320

Lab Sample ID	Client Sample ID	QC Description
<u>Q3320-01</u>	<u>IA1</u>	
<u>Q3320-01DUP</u>	<u>IA1DUP</u>	<u>Sample Duplicate</u>
<u>Q3320-02</u>	<u>SV1</u>	
<u>Q3320-02DL</u>	<u>SV1DL</u>	
<u>Q3320-03</u>	<u>IA2</u>	
<u>Q3320-04</u>	<u>SV2</u>	
<u>Q3320-04DL</u>	<u>SV2DL</u>	
<u>Q3320-05</u>	<u>IA3</u>	
<u>Q3320-06</u>	<u>SV3</u>	
<u>Q3320-07</u>	<u>IA4</u>	
<u>Q3320-08</u>	<u>SV4</u>	
<u>Q3320-08DL</u>	<u>SV4DL</u>	
<u>Q3320-09</u>	<u>IA5</u>	
<u>Q3320-10</u>	<u>SV5</u>	
<u>Q3320-11</u>	<u>IA6</u>	
<u>Q3320-12</u>	<u>SV6</u>	
<u>Q3320-12DL</u>	<u>SV6DL</u>	
<u>Q3320-13</u>	<u>OA1</u>	
<u>VL1008ABL01</u>	<u>VL1008ABL01</u>	<u>Method Blank</u>
<u>VL1008ABS01</u>	<u>VL1008ABS01</u>	<u>Laboratory Control Sample</u>
<u>VL1009ABL01</u>	<u>VL1009ABL01</u>	<u>Method Blank</u>
<u>VL1009ABS01</u>	<u>VL1009ABS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: nishadh

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** nishadh

Date: _____ **Title:** Analyst