

**- COVER PAGE -
ANALYSIS DATA PACKAGE**

Client: JACOBS Engineering Group, Inc.

SDG No.: Q3757 Method Type: EPA SW846 8260 SOW No.: _____

Contract: JACO05 Lab Code: CHEM Case No.: Q3757 SAS No.: Q3757

<u>Lab Sample ID</u>	<u>Client Sample ID</u>	<u>QC Description</u>
<u>Q3757-01</u>	<u>MW-14A-17.5-120325</u>	
<u>Q3757-03</u>	<u>BR-03D-490-120325</u>	
<u>Q3757-05</u>	<u>MW-14B-46-120325</u>	
<u>Q3757-05RE</u>	<u>MW-14B-46-120325RE</u>	
<u>Q3757-07</u>	<u>RMW-05B-90.5-120325</u>	
<u>Q3757-09</u>	<u>OW-05B-72-120325</u>	
<u>Q3757-09RE</u>	<u>OW-05B-72-120325RE</u>	
<u>Q3757-11</u>	<u>EB01-120325</u>	
<u>Q3757-12</u>	<u>TB01-120325</u>	
<u>VN1204WBL01</u>	<u>VN1204WBL01</u>	<u>Method Blank</u>
<u>VN1204WBS01</u>	<u>VN1204WBS01</u>	<u>Laboratory Control Sample</u>
<u>VN1204WBSD01</u>	<u>VN1204WBSD01</u>	<u>Laboratory Control Sample Duplicate</u>
<u>VX1205WBL01</u>	<u>VX1205WBL01</u>	<u>Method Blank</u>
<u>VX1205WBS01</u>	<u>VX1205WBS01</u>	<u>Laboratory Control Sample</u>
<u>VX1208WBL01</u>	<u>VX1208WBL01</u>	<u>Method Blank</u>
<u>VX1208WBS01</u>	<u>VX1208WBS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: maresh

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** maresh

Date: _____ **Title:** Analyst