

- COVER PAGE -  
ANALYSIS DATA PACKAGE

Client: JACOBS Engineering Group, Inc.

SDG No.: Q3787 Method Type: EPA SOM01.2\_SIM SOW No.: \_\_\_\_\_

Contract: JACO05 Lab Code: CHEM Case No.: Q3787 SAS No.: Q3787

| Lab Sample ID      | Client Sample ID                 | QC Description                |
|--------------------|----------------------------------|-------------------------------|
| <u>Q3787-04</u>    | <u>MW-15B-42.5-120425-SIM</u>    |                               |
| <u>Q3787-05MS</u>  | <u>MW-15B-42.5-120425-SIMMS</u>  | <u>Matrix Spike</u>           |
| <u>Q3787-06MSD</u> | <u>MW-15B-42.5-120425-SIMMSD</u> | <u>Matrix Spike Duplicate</u> |
| <u>Q3787-08</u>    | <u>OWBR-02-170-120425-SIM</u>    |                               |
| <u>Q3787-10</u>    | <u>OWBR-02-170-120425-SIM-FD</u> |                               |
| <u>Q3787-12</u>    | <u>OW-03B-51.5-120425-SIM</u>    |                               |
| <u>Q3787-14</u>    | <u>OW-03B-51.5-120425-SIM-FD</u> |                               |
| <u>Q3787-16</u>    | <u>OW-08B-72.5-120425-SIM</u>    |                               |
| <u>Q3787-18</u>    | <u>OW-08B-72.5-120425-SIM-FD</u> |                               |
| <u>Q3787-20</u>    | <u>OW-02B-21.2-120425-SIM</u>    |                               |
| <u>Q3787-21</u>    | <u>TB01-120425</u>               |                               |
| <u>VV1208WBL01</u> | <u>VV1208WBL01</u>               | <u>Method Blank</u>           |
| <u>VV1209WBL01</u> | <u>VV1209WBL01</u>               | <u>Method Blank</u>           |
| <u>VV1210WBL01</u> | <u>VV1210WBL01</u>               | <u>Method Blank</u>           |

Comments: \_\_\_\_\_

\_\_\_\_\_

Signature: \_\_\_\_\_ Name: Shreena

Date: \_\_\_\_\_ Title: Analyst

**Comments:** \_\_\_\_\_  
\_\_\_\_\_

**Signature:** \_\_\_\_\_ **Name:** Shreena

**Date:** \_\_\_\_\_ **Title:** Analyst