

**- COVER PAGE -
ANALYSIS DATA PACKAGE**

Client: JACOBS Engineering Group, Inc.

SDG No.: Q3787 Method Type: EPA SW846 8260 SOW No.: _____

Contract: JACO05 Lab Code: CHEM Case No.: Q3787 SAS No.: Q3787

Lab Sample ID	Client Sample ID	QC Description
<u>Q3787-01</u>	<u>MW-15B-42.5-120425</u>	
<u>Q3787-02MS</u>	<u>MW-15B-42.5-120425-MS</u>	<u>Matrix Spike</u>
<u>Q3787-03MSD</u>	<u>MW-15B-42.5-120425-MSD</u>	<u>Matrix Spike Duplicate</u>
<u>Q3787-07</u>	<u>OWBR-02-170-120425</u>	
<u>Q3787-07RE</u>	<u>OWBR-02-170-120425RE</u>	
<u>Q3787-09</u>	<u>OWBR-02-170-120425-FD</u>	
<u>Q3787-09RE</u>	<u>OWBR-02-170-120425-FDRE</u>	
<u>Q3787-11</u>	<u>OW-03B-51.5-120425</u>	
<u>Q3787-11RE</u>	<u>OW-03B-51.5-120425RE</u>	
<u>Q3787-13</u>	<u>OW-03B-51.5-120425-FD</u>	
<u>Q3787-13RE</u>	<u>OW-03B-51.5-120425-FDRE</u>	
<u>Q3787-15</u>	<u>OW-08B-72.5-120425</u>	
<u>Q3787-17</u>	<u>OW-08B-72.5-120425-FD</u>	
<u>Q3787-17RE</u>	<u>OW-08B-72.5-120425-FDRE</u>	
<u>Q3787-19</u>	<u>OW-02B-21.2-120425</u>	
<u>Q3787-21</u>	<u>TB01-120425</u>	
<u>VX1208WBL01</u>	<u>VX1208WBL01</u>	<u>Method Blank</u>
<u>VX1208WBS01</u>	<u>VX1208WBS01</u>	<u>Laboratory Control Sample</u>
<u>VX1210WBL01</u>	<u>VX1210WBL01</u>	<u>Method Blank</u>
<u>VX1210WBS01</u>	<u>VX1210WBS01</u>	<u>Laboratory Control Sample</u>

Comments: _____

Signature: _____ Name: Shreena

Date: _____ Title: Analyst

Comments: _____

Signature: _____ **Name:** Shreena

Date: _____ **Title:** Analyst