







Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016




Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016




Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016




Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016



Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016



Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016



Method Name: Z:\HPCHEM1\BNA_M\METHODS\8270-SIM-BM030816.M
Calibration Table Last Updated: Tue Mar 08 18:22:06 2016