



PERCENT SOLID

Analyst Name: sweta
Date: 1/3/2018

OVENTEMP IN Celsius(°C): 103
Time IN: 09:00
In Date: 01/02/2018
Weight Check 1.0g: 1.00 g
Weight Check 10g: 10.00 g
OvenID: M Oven-1

OVENTEMP OUT Celsius(°C): 106
Time OUT: 13:20
Out Date: 01/02/2018
Weight Check 1.0g: 1.00 g
Weight Check 10g: 10.00 g
BalanceID: M SC-1

QC: LB92450

<u>Lab ID</u>	<u>Client Sample ID</u>	<u>Dish#</u>	<u>Dish Wt(g)</u> <u>(A)</u>	<u>Dish +</u> <u>Sample Wt(g)</u> <u>(B)</u>	<u>Dish + Dry</u> <u>Sample Wt(g)</u> <u>(C)</u>	<u>% Solid</u>
I7077-02	SB-07-COMP	1	1.15	9.96	9.06	89.8
I7077-04	SB-21-COMP	2	1.14	9.95	8.72	86

$$\% \text{ Solid} = \frac{(C-A) * 100}{(B-A)}$$

PERCENT SOLID

Analyst Name: sweta
Date: 1/2/2018

OVENTEMP IN Celsius(°C): 103
Time IN: 09:00
In Date: 01/02/201
Weight Check 1.0g: 1.00 g
Weight Check 10g: 10.00 g
OvenID: M Oven-1

OVENTEMP OUT Celsius(°C): 106
Time OUT: 12:05
Out Date: 01/02/201
Weight Check 1.0g: 1.00 g
Weight Check 10g: 10.00 g
BalanceID: M SC-1

QC: LB92450

Lab ID	Client Sample ID	Dish#	Dish Wt(g) (A)	Dish + Sample Wt(g) (B)	Dish + Dry Sample Wt(g) (C)	% Solid
I7077-02	SB-07-COMP	1	1.15	9.96	9.07	89.9
I7077-04	SB-21-COMP	2	1.14	9.95	8.73	86.2

$$\% \text{ Solid} = \frac{(C-A) * 100}{(B-A)}$$

WORKLIST(Hardcopy Internal Chain)

LB 92450

WorkList Name : %SOLID I7077

WorkList ID : 107094

Date : 1/2/2018 08:45:15AM

Due Date	Matrix	Sample	Test	Preservative	Customer	Storage Location	Customer Sample	Collect Date	Method
	Solid	I7077-02	Percent Solids	Cool 4 deg C	LIR001	H22	SB-07-COMP	12/22/2017	Chemtech-SO
	Solid	I7077-04	Percent Solids	Cool 4 deg C	LIR001	H22	SB-21-COMP	12/22/2017	Chemtech-SO

Date/Time 1/2/18 8:55 AM

Received by: SP

Relinquished by:

Date/Time 1/2/18 9:30 AM

Received by: SP

Relinquished by: