



PERCENT SOLID

Supervisor: apatel
Analyst: JIGNESH
Date: 10/31/2018

OVENTEMP IN Celsius(°C): 107
Time IN: 16:00
In Date: 10/30/2018
Weight Check 1.0g: 1.00
Weight Check 10g: 10.00
OvenID: M Oven-1

OVENTEMP OUT Celsius(°C): 103
Time OUT: 07:40
Out Date: 10/31/2018
Weight Check 1.0g: 1.00
Weight Check 10g: 10.00
BalanceID: M Sc-1

QC:LB98926

<u>Lab ID</u>	<u>Client Sample ID</u>	<u>Dish#</u>	<u>Dish Wt(g)</u> <u>(A)</u>	<u>Dish +</u> <u>Sample Wt(g)</u> <u>(B)</u>	<u>Dish + Dry</u> <u>Sample Wt(g)</u> <u>(C)</u>	<u>% Solid</u>
J5521-05	AOC8-03B	1	1.14	9.58	8.38	85.8
J5521-07	AOC8-02B	2	1.16	9.77	5.62	51.8

$$\% \text{ Solid} = \frac{(C-A) * 100}{(B-A)}$$

PERCENT SOLID

Supervisor: apatel
Analyst: JIGNESH
Date: 10/31/2018

OVENTEMP IN Celsius(°C): 107
Time IN: 16:00
In Date: 10/30/2018
Weight Check 1.0g: 1.00
Weight Check 10g: 10.00
OvenID: M Oven-1

OVENTEMP OUT Celsius(°C): 103
Time OUT: 07:40
Out Date: 10/31/2018
Weight Check 1.0g: 1.00
Weight Check 10g: 10.00
BalanceID: M Sc-1

QC:LB98926

Lab ID	Client Sample ID	Dish#	Dish Wt(g) (A)	Dish + Sample Wt(g) (B)	Dish + Dry Sample Wt(g) (C)	% Solid
J5521-05	AOC8-03B	1	1.14	9.58	8.38	85.8
J5521-07	AOC8-02B	2	1.16	9.77	5.62	51.8

$$\% \text{ Solid} = \frac{(C-A) * 100}{(B-A)}$$

PERCENT SOLID

Supervisor: 
 Analyst: JIGNESH
 Date: 10/30/2018

OVENTEMP IN Celsius(°C): 107
 Time IN: 12:25
 In Date: 10/30/2018
 Weight Check 1.0g: 1.00
 Weight Check 10g: 10.00
 OvenID: M Oven-1

OVENTEMP OUT Celsius(°C): 103
 Time OUT: 15:50
 Out Date: 10/30/2018
 Weight Check 1.0g: 1.00
 Weight Check 10g: 10.00
 BalanceID: M Sc-1

QC:LB98926

Lab ID	Client Sample ID	Dish#	Dish Wt (g) (A)	Dish + Sample Wt (g) (B)	Dish + Dry Sample Wt (g) (C)	% Solid
J5521-05	AOC8-03B	1	1.14	9.58	8.38	85.8
J5521-07	AOC8-02B	2	1.16	9.77	5.62	51.8

$$\% \text{ Solid} = \frac{(C-A) * 100}{(B-A)}$$