



PERCENT SOLID

Analyst Name: sweta
Date: 1/15/2018

OVENTEMP IN Celsius(°C): 106
Time IN: 08:55
In Date: 01/15/2018
Weight Check 1.0g: 1.00 g
Weight Check 10g: 10.00 g
OvenID: M Oven-1

OVENTEMP OUT Celsius(°C): 103
Time OUT: 01:10
Out Date: 01/15/2018
Weight Check 1.0g: 1.00 g
Weight Check 10g: 10.00 g
BalanceID: M Sc-1

QC: 1b92603

<u>Lab ID</u>	<u>Client Sample ID</u>	<u>Dish#</u>	<u>Dish Wt(g)</u> <u>(A)</u>	<u>Dish +</u> <u>Sample Wt(g)</u> <u>(B)</u>	<u>Dish + Dry</u> <u>Sample Wt(g)</u> <u>(C)</u>	<u>% Solid</u>
J1138-01	WC-10257-01-TM	1	1.16	9.76	8.47	85
J1138-01DUP	WC-10257-01-TMDUP	2	1.17	9.95	8.66	85.3

$$\% \text{ Solid} = \frac{(C-A) * 100}{(B-A)}$$

PERCENT SOLID

Analyst Name: sweta
 Date: 1/15/2018
 OVENTEMP OUT Celsius(°C): 103
 Time OUT: 11:45
 Out Date: 01/15/2018
 Weight Check 1.0g: 1.00 g
 Weight Check 10g: 10.00 g
 BalanceID: M SC-1

OVENTEMP IN Celsius(°C): 106
 Time IN: 08:55
 In Date: 01/15/2018
 Weight Check 1.0g: 1.00 g
 Weight Check 10g: 10.00 g
 OvenID: M Oven-1

QC: 1b92603

Lab ID	Client Sample ID	Dish#	Dish Wt(g) (A)	Dish + Sample Wt(g) (B)	Dish + Dry Sample Wt(g) (C)	% Solid
J1138-01	WC-10257-01-TM	1	1.16	9.76	8.48	85.1
J1138-01DUP	WC-10257-01-TMDUP	2	1.17	9.95	8.67	85.4

$$\% \text{ Solid} = \frac{(C-A)}{(C-A) * 100} (B-A)$$

WORKLIST(Hardcopy Internal Chain)

LB 92603

WorkList Name : %solid011518

WorkList ID : 107393

Date : 1/15/2018 8:36:19 AM

Due Date	Matrix	Sample	Test	Preservative	Customer	Storage Location	Customer Sample	Collect Date	Method
01/14/2018	Solid	J1138-01	Percent Solids	Cool 4 deg C	ENTA04	K22	WC-10257-01-TM	01/12/2018	Chemtech-SO

Date/Time

01/15/18 8:45 AM

Received by:

SP

Relinquished by:

SP

Date/Time

01/15/18 9:30 AM

Received by:

SP

Relinquished by:

SP